



Setup & Instructions

Power Adapter 2. HDMI cord is connected to "TV Box", and the other side is connected TV HDMI interface 3. Connect to the power adapter, the machine automatically boot into the Android OS 4. The wireless mouse receiver is connected to TV Box USt interface, Then you can use wireless mouse to operate it interface.

TV Box Connection Settings

Android Media Center Setup (please Read First)

- 1. Unpack your Android box
- 2. Plug in the supplied HDMI cable to your TV
- 3. Plug in the supplied power cord to the Android box. Hold Power Button for 3 sec. to power on
- 4. If you are supplied with a keyboard mouse (optional) open the back and take out the USB stick & plug it into the USB port on your Android box
- 5. If the keyboard mouse requires charging, plug it into the addition USB port on your Android box. (With supplied cable) Before you can use your Kodi Media center you need to set up your WIFI
- 6. WIFI Setup Click the Settings Icon upper right corner on your MXIII Android Box
- 7. WIFI Setup Click the WIFI box
- 8. WIFI Setup -All the WIFI connections in your area will show up
- 9. WIFI Setup -Click on your WIFI connection, it will ask you for your password
- 10. WIFI Setup Enter your password & then push the connect button at the bottom
- 11. WIFI Setup If you entered the password correctly you should get a connection
- 12. **WIFI Setup** –Push Esc or back button on keyboard to Exit the settings
- 13.**Ethernet Cable** Setup- plug the Ethernet cable directly from router to the Android TV box. Check the box under network settings or it will use WIFI
- 14. On the desk top click on the light blue **KODI** icon
- 15. Wait for it to load and it will automatically down load all the updates (could take a few minutes Please wait)

Kodi Media Center Maintenance

- 1. When you watch a lot of TV shows or movies, Kodi Media center will create a Cache file (this is like a temporary file so the movie can buffer without cutting out)
- 2. You need to clear the Cache after watching 3 4 movies, this will speed up the box and keep movies from cutting out while you are watching.

How to clear the Cache

- 1.On the Kodi Desktop under Cleaners Click on the Maintenance Icon beneath the Cleaner Tab
- 2. Click the **Delete Cache Icon** A box will pop up **(done clearing Cache)** your Cache has now been cleared push the OK button
- 3. Click the back button or esc button

For all other inquiries go to http://www.newandroidtvbox.com

If for any reason your box needs to be re programmed there will be a \$25.00 charge

THIS PAGE IS ONLY TO BE USED FOR TESTING OF KODI, ANDROID MEDIA BOX AND FOR NO OTHER REASEON

This has no link to Kodi or the brand Kodi What So Ever